


USER INSTRUCTIONS

ES3-49



The Ecostat provides control of the air conditioning.

The  button will switch the air conditioning on or off.

The Ecostat will provide temperature adjustment from 20°C to 26°C

The  button will switch the fan mode between high, medium and low speed.

INNOTECH®

Innovative technology

Australian Owned, Designed & Manufactured
by Mass Electronics Brisbane

Phone: + 61 7 3841 1388 Fax: + 61 7 3841 1644

Email: sales@innotech.com.au www.innotech.com.au

TITLE	ECOSTAT 3 CONTROLLER	
MODEL NO	ES3-49	
DATE	24-06-02	
DRAWN	MEK	REV NO: A
APPROVED		